

HOW TO



**A Simple guide
to applying your
mouldings to any
surface**

You Will Need...



Specific Wood Glue
(any brand, we use Gorilla)



Heat
(a heat gun or griddle)



**Your WoodUbend
Moulding!**



Kitchen Roll
(incase things get messy!)

Step 1

Heat your WoodU bend depending on the size and thickness of the mould this could take a couple of seconds to nearly a minute.



TIP: even if you believe you are sticking the WoodU bend to a completely flat surface we **ALWAYS** recommend heating before application.

Step 2



Apply the Glue

Using a small-tipped brush, apply the glue, an average amount is fine, not too much as to create over-spill once stuck down but not too little that it won't make a difference!

FACT: we always use SPECIFIC wood glue as it adheres best to the moulding and consolidates with the molecular structure of the WoodU bend

Step 3



Press the moulding against the area you want to apply it to. Using some pressure, press the moulding to the surface holding down around the contours,

you may need to introduce a heat gun if the mouldings has cooled during Step 2.

Hold the moulding in place, until cooled, as a general rule a moulding takes equally as long to cool-down as it does to heat up!

TIP: has any excess glue spilled out between the gaps in the mouldings? it is easily wiped away with the likes of a baby wipe, kitchen roll, cotton buds or even your fingers.